




# Star Pillar

## Installation

Components	Assembly	Completed Set Up
		
<p>Included are:</p> <ul style="list-style-type: none"> <li>• 2 vertical sides</li> <li>• Round base</li> <li>• Round top ring</li> <li>• Cylinder top</li> <li>• 1 can gel fuel</li> </ul>	<p>To assemble:</p> <ol style="list-style-type: none"> <li>1. Slide side with bottom slit over top slit side</li> <li>2. Lay sides down, and place base at the bottom</li> <li>3. Turn round base so grooves are between sides and stand unit up</li> <li>4. Place cylinder and ring on top</li> <li>5. Insert gel fuel can inside cylinder</li> </ol>	<p>To install:</p> <p>Place pillar in desired position. May be secured through the center hole in the base with a lag bolt (if necessary).</p>

## Use and Care

<p>Directions for use:</p> <ul style="list-style-type: none"> <li>• Shake can well before using. Use extreme caution and place hand over lid pointed away from face while opening (32 oz. can).</li> <li>• Each can burns 2-3 hours with a beautiful 4-7" vibrant yellow flame and a wonderful crackling sound effect</li> <li>• Only re-use cans for 3-4 fires, then replace with fresh new clean quart cans (found in hardware stores)</li> </ul>	<p>To refill:</p> <ol style="list-style-type: none"> <li>1. Store refill bottle in cool, dark area</li> <li>2. READ ALL DIRECTIONS before refilling</li> <li>3. Shake refill bottle before using</li> <li>4. Pour with caution - if spilled, clean with water and do not light near spillage</li> <li>5. Replace child lock safety cap each time bottle is opened</li> </ol>
<p>Corten Steel – a.k.a. weathering steel, a special alloy that uses copper and nickel to create a weather-resistant surface. Can be left untreated and is maintenance free.</p>	<p>Gel fuel - alcohol based, with water, salt and thickening agents, lasts for 2 years, NOT explosive</p>